

## WARNINGS



### WARNINGS

When using electrical equipment, basic safety precautions should always be followed, including the following:

- All electrical connects must be in accordance with local codes, ordinances, and the Canadian National Electrical Code.

- Read and follow all safety instructions
- Do not let wires touch hot surfaces
- Do not install near gas or electric heaters
- The use of accessory equipment not recommended by manufacturer may cause an unsafe condition and will void the unit's warranty
- Do not use this equipment other than its intended purpose
- Servicing of this equipment should be performed by qualified service personnel
- Save these instructions for future reference
- Do not use outdoors

**ATTENTION RECEIVING DEPARTMENT:** Note actual fixture description of any shortage or noticeable damage on delivery receipt. File claim for common carrier (LTL) directly with carrier. Claims for concealed damage must be filed within 15 days of delivery. All damaged material, complete with original packaging must be retained.

## INSTALLATION INSTRUCTIONS

**WARNING:** Over-tightening the canopy mounting screws may damage the canopy base and cause this product to become defective.

- Ensure power is not live. Make wiring connections and observe polarity. Red (+), Black (-). Refer to Fig. 1.
- Install the canopy to the junction box by using the provided junction box mounting plate.
- Apply power.

## LAMP HEAD ADJUSTMENT

- To rotate the heads, loosen the nut attached to the base of each remote head, located beneath the canopy. Once loosened, rotate the remote heads into the desired position and retighten the nut to secure the position.
- To tilt the heads, push the head up and down to desired tilt angle.




Fig. 1